SAMSUNG ELECTRONICS

Enterprise IP Solutions

OfficeServ

Softphone PPC User Guide

COPYRIGHT

This manual is proprietary to SAMSUNG Electronics Co., Ltd. and is protected by copyright.
No information contained herein may be copied, translated, transcribed or duplicated for any commercial purposes or disclosed to third parties in any form without the prior written consent of SAMSUNG Electronics Co., Ltd.

TRADEMARKS

Product names mentioned in this document may be trademarks and/or registered trademarks of their respective companies.

This manual should be read before the installation and operation, and the operator should correctly install and operate the product by using this manual.

This manual may be changed for the system improvement, standardization and other technical reasons without prior notice.

For further information on the updated manual or have a question the content of manual, contact **Document Center** at the address below.

Address: Document Center 2nd Floor IT Center. Dong-Suwon P.O. Box 105, 416, Metan-3dong Yeongtong-gu, Suwon-si, Gyeonggi-do, Korea 442-600

e-mail: manual@samsung.com

http://www.samsungdocs.com

©2004 SAMSUNG Electronics Co., Ltd. All rights reserved.

INTRODUCTION

Purpose

PDA Softphone is a telephony application that operates by inter-working with the OfficeServ 500 system based on a PDA. This document describes the methods of controlling a variety of calls such as intercom or external calls and using the functions of the PDA Softphone by using the PDA Softphone.

Document Content and Organization

This document consists of six chapters as summarized below:

CHAPTER 1. PDA Softphone Overview

This chapter introduces the configuration and functions of the PDA Softphone and describes procedures for PDA Softphone setup.

CHAPTER 2. Description of the PDA Softphone

This chapter describes the windows of the PDA Softphone and option settings.

CHAPTER 3. Making/Answering Calls

This chapter describes functions of making or answering calls using the PDA Softphone.

CHAPTER 4. Convenient Features

This chapter describes the address book and message functions provided by the PDA Softphone.

© SAMSUNG Electronics Co., Ltd.

ANNEX A. ABBREVIATION

Appendix A introduces the acronyms frequently used in this document and their full terms.

Conventions

The following special paragraphs are used in this document to point out information that must be read. This information may be set-off from the surrounding text, but is always preceded by a bold title in capital letters.

CHECKPOINT

Provides the operator with checkpoints for stable system operation.

NOTE

Indicates additional information as a reference.

References

OfficeServ ITP-5012L User Guide

The OfficeServ ITP-5012L User Guide provides instructions for the latest Samsung ITP-5012L large LCD IP Phone that can be used by inter-working with the Enterprise IP Solutions OfficeServ system of Samsung.

OfficeServ 500 General Description Guide

The OfficeServ 500 General Description Guide describes the major functions of the systems, products, cabinet configuration, and boards.

Revision History

EDITION	DATE OF ISSUE	REMARKS
00	03. 2004.	Original
01	10.2004	Softphone V1.1
02	02.2006	Softphone PPC V1.1.1.0

© SAMSUNG Electronics Co., Ltd.

TABLE OF CONTENTS

INTRODUCTION III

Purpose III
Document Content and Organization III
Conventions IV
References IV
Revision History IV

CHAPTER 1. PDA Softphone Overview 1

Introduction to the PDA Softphone 1
Configuration of the PDA Softphone 3
Features of the PDA Softphone 4
PDA Softphone Setup 5
Preparations Prior to Installation 5
PDA Softphone Setup 6
Initial Environment Settings for the PDA Softphone 10

CHAPTER 2. Description of the PDA Softphone 13

PDA Softphone Windows Description 13
Initial Window of the PDA Softphone 13
PDA Softphone Option Settings 19
Option Tab 20
Device Config. Tab 22
System Config. Tab 27
Forward Tab 31

CHAPTER 3. Making/Answering Calls 32

Making a Call 33
Making an Intercom Call 33
Making an External Call 34
Making a Call Using the Recent Call Log 34

© SAMSUNG Electronics Co., Ltd.

Answering a Call **35**
Answering an Intercom Call 35
Making an External Call 35
Conference Call **36**

CHAPTER 4. Convenient Features **38**

Contacts **38**
Registering Phone Numbers 39
Modifying Phone Numbers 41
Deleting Phone Numbers 42
Making a Call Using PDA Contacts 42
Message Box **44**
Sending Message 44
Sent Messages 45
Received Messages 46
Message Box 47
Call Log **48**
Audio Config **50**

ANNEX A. ABBREVIATION **52**

A 52
D 52
O 52
P 52

© SAMSUNG Electronics Co., Ltd.

CHAPTER 1. PDA Softphone Overview

This chapter introduces the configuration and functions of the PDA Softphone and describes procedures for installing the PDA Softphone program.

Introduction to the PDA Softphone

The PDA Softphone is a telephony application that operates by inter-working with the OfficeServ 500 system based on a PDA. The PDA Softphone allows the users to make intercom or external calls and use a variety of functions provided by Softphone.

Intercom Calls

Making an intercom call means that the Softphone user who is connected to the phone system of the user's office makes a call to another internal PDA Softphone(or phone) user.



© SAMSUNG Electronics Co., Ltd.

External Calls

Making an external call means that the user makes a call to outside places(e.g. home) or answers a call made from outside by using the Softphone(or phone) directly connected to the PBX of the central office.



© SAMSUNG Electronics Co., Ltd.

Configuration of the PDA Softphone

The PDA Softphone is used on the Intranet connected to the OfficeServ 500 system and transfers or receives data in a UDP method.

The configuration diagram of the PDA Softphone is shown below:



© SAMSUNG Electronics Co., Ltd.

Features of the PDA Softphone

The PDA Softphone provides a variety of services such as call control, automatic redial, conference call, call forwarding, DND, and caller ID check.

Call Control

The PDA Softphone allows the user to use all of the default or expanded services of Samsung Digital Cellular System(DCS) switching system. Also, the PDA Softphone allows the user to make, answer, or release a call and manage multiple calls. Also, the user is available for various calling functions without remembering the functional codes of the phone.

Conference

The PDA Softphone allows multiple people to hold a conference call. This function allows up to 5 people to speak to one another.

Call Forwarding

This function allows the user to forward any calls, which are connected when the user is on the phone, to another station.

Address book

The PDA Softphone provides a address book so that the user can register contacts with the PDA for easy management. The address book allows the user to make calls easily.

Message

This function allows the user to create or receive messages between the Softphone(or phone) users.

Caller ID Check

This function enables the caller ID and name to be displayed in the main window of the PDA Softphone when a call is connected.

Low Battery/Low level WLAN Alert

This function enables the Alert popup message to be displayed in the main window of the PDA Softphone when a Battery is low and a WLAN level is low.

© SAMSUNG Electronics Co., Ltd.

PDA Softphone Setup

This section describes preparations prior to PDA Softphone setup and procedures for installing the PDA Softphone into the PDA.

Preparations Prior to Installation

Check the following prior to PDA Softphone setup:

Hardware Requirements

The table below shows the recommendations for installing and using the PDA Softphone:

Category	Specification
Operating System	Pocket PC 2002 or 2003
CPU	400 MHz, Intel XScale or higher
Memory	64 MByte or higher
Resolution	240×320 or higher

Checkpoints

Check the following prior to PDA Softphone setup:

- Check if the PC where the PDA Softphone setup program exists is connected to the PDA into which the PDA Softphone will be installed.
- IP address of the OfficeServ system MCP that enables the PDA Softphone with the OfficeServ system.
- Device ID and ID password for operating the PDA Softphone properly.

© SAMSUNG Electronics Co., Ltd.

PDA Softphone Setup

Follow the steps below to install the PDA Softphone:

1 Download the PDA Softphone installation program(version for PDA Keyphone) from the web site that provides the OfficeServ system on a PC, and double click and run ‘OfficeServ Softphone PPC Install_1.1.1.0.exe’. Then, the installation window below will appear:

Once the installation preparation window appears, a window that prompts you to select a country where OfficeServ Softphone will be used appears.


Softphone Setup
Welcome to the InstallShield Wizard for OfficeServ Softphone PDA
The InstallShield(R)Wizard will install OfficeServ Softphone PDA on your PDA Device. Select your country and click Next to continue.
An appropriate EULA (End User License Agreement) will be displayed according to the country you select.
Country:
United States
< Back
Next >
Cancel

Click [Next>] to continue setup.

NOTE

PDA Softphone setup

Connect the PDA where the PDA Softphone will be installed with the PC by a cable and install the PDA Softphone program into the PDA by using the PC.

© SAMSUNG Electronics Co., Ltd.

2 The window that displays the PDA Softphone license agreement appears as shown below:


Softphone Setup
License Agreement
Please read the following license agreement carefully.
Press the PAGE DOWN key to see the rest of the agreement.
Software License Agreement & Limited Warranty
For OfficeServ Softphone for iDCS Keyphone Series.
Samsung Telecommunications America, L.P.
IMPORTANT, READ CAREFULLY:
==========
This Samsung End-User License Agreement (EULA) is a legal binding agreement between you (either an individual or an entity) and Samsung for Samsung software product identified above, which includes computer software and may include printed material, and
Do you accept all the terms of the preceding License Agreement? If you select No, the setup will close. To install Samsung OfficeServ Softphone PDA, you must accept this agreement.
InstallShield
< Back
Yes
No

3 The window that prompts the user to install the program into the default application setup directory(\Program Files\Samsung Electronics\OfficeServ Softphone\) will appear as shown below:



If the user wants to install the program into the default application setup directory, click [Yes].

NOTE

PDA Softphone setup directory

It is recommended that the PDA Softphone should be installed into the default directory.

4 Install the program into the PDA using the PC as shown below:


Add/Remove Programs
Select a program's check box if you want to install it on your mobile device, or clear the check box if you want to remove the program from your device.
Note: If a program that you installed is not listed, the program was not designed to be used on your mobile device.
Installing Applications
Installing Samsung Softphone...
Cancel
Space required for selected programs:
Space available on device:
Install program into the default installation folder
Remove from both locations
To remove the selected program from both your device and this computer, click Remove.
Remove...
OK
Cancel
Help

5 Once the window below appears, click [OK] and check the PDA window:

Application Downloading Complete
Please check your mobile device screen to see if additional steps are necessary to complete this installation.
OK

© SAMSUNG Electronics Co., Ltd.

6 The program is installed into the PDA automatically and the window that displays setup progress appears in the PDA as shown below:

7 Once the program is installed into the PDA properly, the window disappears.

Initial Environment Settings for the PDA Softphone

This section describes the method of getting started with the PDA Softphone and setting login information after installing the PDA Softphone.

1. Run the Softphone program on the PDA where the PDA Softphone is installed.
2. If the user runs the PDA Softphone for the first time after setup, the environment settings message will appear in the initial window as shown below:

NOTE

Initial Environment Settings for PDA Softphone

If the user runs the PDA Softphone for the first time after setup, the user should set login information to use a variety of PDA Softphone functions.

© SAMSUNG Electronics Co., Ltd.

3 Click the [Option Config.] icon( ) from the initial window of the PDA Softphone, and click the [System Config.] tab.



4 Select [Login Info...] from [System Config.]. Then, the window below appears:

- System MCP IP: Type the IP address of the OfficeServ system MCP to be connected with the PDA Softphone.

© SAMSUNG Electronics Co., Ltd.

- Station ID: Type four digits of the station number to be used in the PDA Softphone.
- ID Password: Type the password of the OfficeServ Station ID.

NOTE

Login Information Settings for the PDA Softphone

Enter the login information of the PDA Softphone correctly to operate the PDA Softphone properly. If the user is not aware of the login information, contact the OfficeServ system administrator.

5 After setting login information, click [OK]. To apply the login information settings, the PDA Softphone should be restarted after setting login information.

6 Once the login information is set properly, restart the PDA Softphone. Then, the initial window appears as shown below:

© SAMSUNG Electronics Co., Ltd.

CHAPTER 2. Description of the PDA Softphone

This chapter describes the windows of the PDA Softphone and option settings.

PDA Softphone Windows Description

This section describes the initial and main windows of the PDA Softphone.

Initial Window of the PDA Softphone

Once the login information of the PDA Softphone is set properly, restart the program. Then, the initial window appears as shown below:



© SAMSUNG Electronics Co., Ltd.

The initial window of the PDA Softphone is described below:

Item	Description
Main Window	The main window displays the icons that show function settings, available menus, or messages that show call processing status.
Number Buttons [0]~[9]	Allows the user to enter phone numbers or functional codes.
[*], [#]	Allows the user to enter special characters('*' or '#').
Programmable Feature Control Key Window	This is a functional key displayed in the right window. This window is replaced with the soft menu when the user is on the phone or another soft menu is displayed.
[Call] Button	Allows the user to make or answer a call or retrieve the recent calling history in a wait state.
[Xfer] Button	Allows the user to Transfer while busy-call.
[Hold] Button	Allows the user to Hold while busy-call.
[End] Button	Allows the user to end a call or operating function.
[Contatcs] Icon	Enables the Contacts function. For details, 'Contacts' of 'CHAPTER 4. Convenient Features'.
[Message] Icon	Allows the user to use the message function. For details, 'Message' of 'CHAPTER 4. Convenient Features'.
[Option Config.] Icon	Allows the user to set PDA Softphone options. For details, 'Option Settings' of 'CHAPTER 2. Description of the PDA Softphone'.
[Call Log.] Icon	Allows the user to retrieve originating or receiving calling history.
[Conference] Icon	Allows the user to hold a multi-pointing voice conference call.
[Audio Config.] Icon	Allows the user to adjust the volume of speakers, offhook, or ring Tone and the advnaced voice setting.

© SAMSUNG Electronics Co., Ltd.

Main Window

The main window displays the icons that show function settings, call processing or messages.

The icons displayed in the main window are described below:

Icon	Description
	Wireless LAN Level Guage
	System Link Connection Status(displayed after proper login)
	Softphone Lock ALL
	Softphone Lock Outgoing
	DND
	Mute
	Call Forwarding
	Answering Mode (Auto/Page)
	Phone Message
	Short Text Message
	Battery Level Guage

© SAMSUNG Electronics Co., Ltd.

Programmable Feature Control Window

Program keys that show the functions set in the OfficeServ system are displayed at the right of the number buttons. Select a button to use the corresponding function.



NOTE

Program Key Options

Program key options depend on the functions set in the OfficeServ system.

© SAMSUNG Electronics Co., Ltd.

Soft Menu Window

The soft menu window is displayed at the same location as the program keys if required. The soft menus are configured with convenient features that are available during a call from the PDA Softphone. Select a menu to use the corresponding function.

© SAMSUNG Electronics Co., Ltd.

Softphone Minimize (Tray Icon)

Click the [OK] button ( ) from the main window of the PDA Softphone. Then, the Softphone is minimized:

Click the Trat Icon ( ) from the PDA. Then, the Softphone's popup-menu appears as shown below.

Click the [OS Softphone] menu from the popup-menu of the PDA Softphone. Then, the Softphone' is activaed. Click the [Exit] to exit the Softphone.

© SAMSUNG Electronics Co., Ltd.

PDA Softphone Option Settings

This section describes the method of setting a variety of options from the PDA Softphone.

Select the [Option Settings] icon( ) from the initial window of the PDA Softphone to set a variety of PDA Softphone options.

The [Option Config.] menu consists of four tabs as described in the table below:

Tab	Description
Option	Allows the user to set Softphone options.
Device Config.	Allows the user to set user profiles, morning calls, alarms, skins, or ring sounds.
System Config.	Allows the user to set system options.
Forward	Allows the user to set a station number to which a call is transferred when the Softphone is not used or the user cannot answer a call.

© SAMSUNG Electronics Co., Ltd.

Option Tab

The [Option] tab allows the user to set options such as news scroll speed or message display.



Preference	Option	Description
Normal	News Scroll Speed	Allows the user to set a news scroll speed(Slow/Normal/Fast).
Message	View Message upon receipt	Enables a message to be displayed when the message is received.
	Message Alarm	Allows the user to set the cycle of an alarm when a message is received. - Once: An alarm rings only once when a message is received. - Every 2 Min.: An alarm rings every two minutes until the user checks a message. - No Tone: An alarm does not ring even when a message arrives.
	Alarm Sound	Allows the user to select a sound that notifies the user that a message has arrived.
	Status Info.	Allows the user to check Softphone settings and properties.

© SAMSUNG Electronics Co., Ltd.

Alarm Sound...

Click [Alarm Sound...] from the [Option] tab. Then, the window that prompts the user to set a wave file(*.wav) appears as shown below: Select a required wave file for a message sound.

Status Info...

Select [Status Info...] from the [Option] tab. Then, the <Status Info.> window appears as shown below:



Device Config. Tab

The [Device Config.] tab allows the user to set user profiles, morning calls, alarms, skins, or ring sounds.



Preference	Option	Description
Device Option	Station Name	Allows the user to set a name to be displayed in the called party's Softphone when making a call.
	Change Password	Allows the user to change a password that enables privacy and phone initialization.
	Privacy Option	Allows the user to set options to prevent other users from using the user's profile and set the privacy function in functions such as address book, message box, and calling history check.
Ring	Ring Tone	Allows the user to select a ring tone.

© SAMSUNG Electronics Co., Ltd.

Change Password.

Click [Change Password] from the [Device Config.] tab. Then, the window below appears:



- Password: Type the existing password.(The initial password is ‘1234’.)
- New Password: Type a new password.
- Re-type Password: Type a new password again.

Type the existing and new password and select [Save].

NOTE

In case that the user is not aware of password

If the user is not aware of password, set ‘login information’ again. Set a password in [Password] of [Option] → [System Config.] → [Login Info...].

Privacy Option...

Click [Privacy Option...] from the [Device Config.] tab. Then, the window that prompts the user to enter a password appears as shown below:

NOTE

Entering a password for privacy

Enter a password correctly to use the privacy function. If the entered password mismatches the setup password, the user cannot use the privacy function.

© SAMSUNG Electronics Co., Ltd.

Enter a password and click [OK]. Then, the window that prompts the user to set the privacy function appears as shown below:



Click [Yes] to set the privacy function. Click [No] to release the privacy function. Once the privacy function is set, the window below appears:



NOTE

Privacy Function Settings

Once the privacy function is set, the password should be entered to use the [Option], [Directory], or [Message] function.

© SAMSUNG Electronics Co., Ltd.

Ring Tone

Click [Ring Tone] from the [Device Config.] tab. Then, the window below appears:

- Select one of the default ring sounds or click [Search...] to select a wave file.
- Click the [Play] button to listen to a wave file in advance.

Select a ring sound and click [OK].

© SAMSUNG Electronics Co., Ltd.

System Config. Tab

The [System Config.] tab allows the user to set system options.



[Station] of the [System Config.] tab allows the user to set a variety of functions such as dial mode, dial timeout, or response mode.

Preference	Option	Description
Station	Dial Mode	Allows the user to select a dial mode(Enbloc/Overlap). - Enbloc: This mode is set by default. This mode allows the user to delete an invalid phone number and enter the number again when the user presses the invalid number. Press the phone number and click [Call] to make a call. - Overlap: When pressing a phone number, a call is connected immediately. If an invalid phone number is pressed, click the [End] button to hang up the phone and enter the phone number again.

© SAMSUNG Electronics Co., Ltd.

Preference	Option	Description
	Internal Call Display	Allows the user to set the display in the station buttons of the <Programmable Feature Control> window. - Number: Enables station numbers to be displayed in the <Programmable Feature Control Key> window. - Number+Name: Enables number+names to be displayed in the <Programmable Feature Control Key> window.
	Answering	Allows the user to set an answer mode of the Softphone when a call is connected. - Ringing: Enables the phone to ring when a call is connected. - Auto Answer Mode: Enables a call to be connected when the call is made. - Voice Announce Mode: Allows the user to hear the caller's voice while a speaker turns on when a call is made. The caller cannot hear the voice of the called party. Click the [Call] button to speak to the caller.
	Station Lock	Allows the user to set the Locked All function to prevent other users from using the Softphone. - Unlocked: Disables the lock function. - Locked Outgoing: Disables outgoing. - Locked All Calls: Disables outgoing or incoming.
	LANGUAGE	Allows you to select a language to be used in OfficeServ Softphone. - English: Allows you to set the Softphone language to English. - Korean: Allows you to set the Softphone language to Korean. - Italian: Allows you to set the Softphone language to Italian.

Preference	Option	Description
Station	Absent Message	Allows the user to set or release a message to be displayed in the Softphone of the caller while the user is absent.
	Login Info.	Allows the user to set Softphone login information. For details, refer to 'Initial Settings for the PDA Softphone'.
	Phone Reset	Allows the user to delete user data such as message boxes, calling histories

© SAMSUNG Electronics Co., Ltd.

Phone Reset

Click [Phone Reset] of the [System Config.] tab. Then, the window that prompts the user to enter a password appears as shown below:



Enter a password and click the [OK] button. Then, the window below appears:



Click the [YES] button to initialize the phone. Then, the Initialization Complete message will appear. Click the [No] button to cancel the initialization of the phone.

NOTE

Initialization of the Phone

Take note that data such as all message box, call log will be deleted when the phone is initialized.

© SAMSUNG Electronics Co., Ltd.

Absent Message...

Click [Absent Message...] from the [System Config.] tab. Then, the window below appears:



Select an absent message, and click the [OK] button to set an absent message. Click the [Clear] button to release an absent message.

NOTE

Absent Message

The messages of No. 1 to 15 are registered with the system. The messages of No. 16 to 20 can be modified and used by the PDA Softphone users directly. Select a message to be modified from the messages of No. 16 to 20, and click [Edit] to modify an absent message.

© SAMSUNG Electronics Co., Ltd.

Forward Tab

The [Forward] tab allows the user to set a station number to which an incoming call will be transferred when the user does not use the Softphone or cannot answer a call.



- Disable: Allows the user to release call forwarding.
- Always: Allows the user to enter a station number to which all incoming calls will be transferred.
- BUSY: Allows the user to enter a station number to which an incoming call will be transferred when the user is on the phone.
- No Answer: Allows the user to enter a station number to which an incoming call will be transferred when the user cannot answer the call.
- BUSY/No Answer: Allows the user to enter a station number to which an incoming call will be transferred when the user is on the phone or cannot answer the call.
- DND: Allows the user to enter a station number to which an incoming call will be transferred when the user does not want to answer the call.
- Follow Me: If another Softphone(or phone) user sets call forwarding in Softphone of the user, the phone number of the user will be displayed.

© SAMSUNG Electronics Co., Ltd.

CHAPTER 3. Making/Answering Calls

This chapter describes a variety of functions for making or answering calls by using the PDA Softphone.

Making a Call

Default and additional functions for making an intercom call or an external call are as follows:

Category	Intercom Call	External Call
Default Functions	Making an intercom call, Answering an intercom call	Making an external call, Answering an external call
	Conference call	
Additional Functions	- Making a call using the recent call log - Making a call using the Address book window	

© SAMSUNG Electronics Co., Ltd.

Making a Call

This section describes the functions for making a call using the PDA Softphone.

Making an Intercom Call

Follow the steps below to make an intercom call:

1 Enter the target station number, and click the [Call] button. The ring-back tone rings.

NOTE

Ring-back Tone

If the voice announce mode or auto answer mode is set in the station of the called party, a short tone rings instead of a ring-back tone when the [Call] button is clicked. In this case, the user can speak to the called party when the short tone ends.

2 Speak to the called party when the called party answers the call.

NOTE

Dial Mode

- The 'Enbloc mode' is set in the PDA Softphone by default. Press a phone number, and click the [Call] button to make a call.
- For the details of the dial mode, refer to 'System Config. Tab' of the 'PDA Softphone Option Settings.'

3 Click the [End] button to end the call.

© SAMSUNG Electronics Co., Ltd.

Making an External Call

Follow the steps below to make an external call:

1. Enter the phone number of the called party including the external calling number, and click the [Call] button. Then, the ring-back tone rings.
2. Speak to the called party after the called party answers the call.
3. Click the [End] button to end the call.

Making a Call Using the Recent Call Log

This function allows the user to make a call using the recent call log.

1. Click the [Call] button in a wait state. Then, the window below appears:

2. Press the [Call] button with the call log selected. Then, the call is made.

> NOTE
>
> **Recent Call Log Deletion**
>
> Select the target call log from the recent call log, and click the [Delete] button.

3. Speak to the called party after the called party answers the call.
4. Click the [End] button to end the call.

© SAMSUNG Electronics Co., Ltd.

Answering a Call

This section describes the functions for answering a call using the PDA Softphone.

Answering an Intercom Call

Follow the steps below to answer an intercom call:

1. When an intercom call is connected to the PDA Softphone, the PDA Softphone rings and displays a message notifying the user that a call is connected.

2. Click the [Call] button to answer the call.
3. Click the [End] button to end the call.

Making an External Call

Follow the steps below to answer an external call:

1. When an external call is connected to the PDA Softphone, the PDA Softphone rings and displays a message notifying the user that a call is connected.
2. Click the [Call] button to answer the call.
3. Click the [End] button to end the call.

© SAMSUNG Electronics Co., Ltd.

Conference Call

This function allows the user to hold a conference call with up to five people(connected to stations or C.O.lines) including the user simultaneously using the PDA Softphone.

1 Click the [Conference] icon( ) in a wait state. Then, the window below appears:



2 After entering the target numbers, select the [Select] check box and click the [Dial All] button. If a group is already registered, the user can select the group.

© SAMSUNG Electronics Co., Ltd.

3 If the user wants to release a call during a conference, click the [Delete] button in the corresponding list. Or, enter numbers to be connected in the vacant fields, and click the [Call] button.



4 Click [Exit] to end the conference call.

CHAPTER 4. Convenient Features

This chapter describes method of using the contacts and message box of the PDA Softphone.

Contacts

This section describes the functions of the Contacts of the PDA Softphone.

Click the [Contacts] icon( ) from the initial window of the PDA Softphone. Then, the window below appears:



Registering Phone Numbers

This function allows the user to save phone numbers in the PDA Contacts. Up to four phone numbers(home, mobile phone, office, and others) per person can be saved. In addition, facsimile numbers, e-mail addresses, groups, and notes can be registered.

NOTE

PDA Softphone Address book

PDA Softphone Contacts is used identically with the contact data of a PDA installed the PDA Softphone program.

1 Select [Edit] from the address book. Then, the window below appears:



© SAMSUNG Electronics Co., Ltd.

2 Select [New]. Then, the window below appears:



3 Enter the user information to be registered, and click the [ok] button.

© SAMSUNG Electronics Co., Ltd.

Modifying Phone Numbers

This function allows the user to modify registered phone numbers.

1 Select the target list from the Contacts window. Then, the corresponding window appears.

2 Select [Edit] from the Contacts window. Then, the window below appears:



3 Modify the corresponding information, and click the [ok] button.

Deleting Phone Numbers

This function allows the user to delete registered phone numbers.

1. Select [Edit] from the address book. Then, the PDA Contacts window appears.
2. Select the target phone number to be deleted from the Contacts, and select [Tools] → [Delete].

Making a Call Using PDA Contacts

This function allows the user to make a call using the PDA Contacts menu.

1. Long Select the target phone number from the Contacts, and click the [Call(OS Softphone)] button.



© SAMSUNG Electronics Co., Ltd.

2 Select a target phone number from the Select Phone Number window. Click [Call] to dial the PDA Softphone.



Message Box

This function allows the users to exchange messages between each other.

Click the [Message] icon( ) from the initial window of the PDA Softphone. Then, the window below appears:

Sending Message

1 Select [Send New]. Then, the window below appears:



© SAMSUNG Electronics Co., Ltd.

2 Enter the station number of the user who will receive a message, and enter message text. Then, click the [Send] button.

- Select [Load] to load the message stored in the message box.

Sent Messages

Select [Sent MSG.]. Then, the received messages appear.



- Select a message to verify the message in detail.
- Select [Reply] to send a reply to the user who has sent the message.
- Select [Send New] to send a new message.
- Select [Delete] to delete a selected message.

© SAMSUNG Electronics Co., Ltd.

Received Messages

Select [Received MSG.]. Then, the received messages appear as shown below:

- Select a message to verify the message in detail.
- Select [Reply] to send a reply to the user who has sent the message.
- Select [Send New] to send a new message.
- Select [Delete] to delete a selected message.

© SAMSUNG Electronics Co., Ltd.

Message Box

Select [Draft]. Then, the messages stored in the message box appear as shown below:



- Select [Write] to write a new message.
- Select [Delete] to delete a message.

Writing Message

Select [Write]. Then, the window below appears.



Enter the message text to be stored, and click the [Save] button.

© SAMSUNG Electronics Co., Ltd.

Call Log

This function allows the user to check the call log of the PDA Softphone.

Recent Call Log

Select the [Call Log] icon( ) from the initial window of the PDA Softphone. Then, the window below appears:

- Select [Call] to make a call to a phone number selected from the call log.
- Select [Delete] to delete a call log selected from the call log.

© SAMSUNG Electronics Co., Ltd.

Sent Call Log

Select [Sent Call Log] from the Call Log window. Then, the sent calls appear.

Received Call Log

Select [Received Call Log] from the Call Log window. Then, the received calls appear.

© SAMSUNG Electronics Co., Ltd.

Audio Config

Select the [Audio Config.] icon( ) from the initial window of the PDA Softphone. Then, the window below appears:



Set the volume of each item, and click the [OK] button.

Advances Voice Setting

Select [Voice Codec] from the Voice Config. window. Then, Advanced Voice Configuraion window below appears:



© SAMSUNG Electronics Co., Ltd.

This page is intentionally left blank.

© SAMSUNG Electronics Co., Ltd.

ANNEX A. ABBREVIATION

A

API	Application Programming Interface

D

DSN	Domain Server Name
DTMF	Dual Tone Multi Frequency

O

ODBC	Open DataBase Connectivity

P

PBX	Private Branch eXchange

© SAMSUNG Electronics Co., Ltd.

This page is intentionally left blank.

OfficeServ

Softphone PDA User Guide

©2004 Samsung Electronics Co., Ltd.
All rights reserved.

Information in this document is proprietary to SAMSUNG Electronics Co., Ltd.

No information contained here may be copied, translated, transcribed or duplicated by any form without the prior written consent of SAMSUNG.

SAMSUNG ELECTRONICS